

KIT #2 HINGE ASSEMBLY INSTALLATIONS



1



2



3



4



5



6



7



8



9

10. Proceed to drill through spacers and into boat. Using 16 1/4" 20 screws bolt through fiberglass and apply backing plate.